

Fueling AHTN Vehicles



Advocates for Homeless
& Those in Need

- The driver shall verify that the fuel supply is adequate after each mission and fuel the vehicle as necessary. Complete all guest drop-offs before refueling.
- Never leave the White/ Silver buses with less than a ½ tank of fuel. The TIN Van should never be under ¼ tank.
- Use unleaded gasoline ONLY. *This includes the White Bus.*
- Turn the engine and lights off while fueling. Take the key out and keep with you as well.
- Stay by the pump while fueling.
- Gas cap key can be found:
 - White Bus, on the key ring.
 - TIN Van, kept in binder with gas card
 - Silver Bus- *NO gas cap key needed* since the gas tank door is secured with the driver door.

Please use the Quarles Universal Fueling credit card found inside the black mesh pouch located in the vehicle binder. Receipts should always be printed and kept inside the solid pocket below the mesh one. Any issues with the card, please call 24 hour Customer Service line at: 1-877-444-3835 or contact Crystal Myers, Program Consultant at 215.550.3868 x106 or email Cmyers@ahtn.org

REMINDER: You must enter both the pin code and the current mileage on the vehicle (whole miles only, no tenths). DRIVERS WERE EMAILED THE CODE.

A list of acceptable fueling stations is kept in the vehicle binder. Drivers can also use the Quarles Station at 56 Runway Road, Levittown PA 19057